


Live & Gravity Bulk Part Supply Hoppers

**Pedestal Hopper w/ Active Pan Commonly
Used as buffer accumulation and pre-feeder with all types
of Dyna-Slide bowl and horizontal feeders**




**Table Mounted Hopper w/
Vibratory Drive Pan**



Dyna-Slide®



**Live Pan w/ active pan for unloading customer's
front dump container. Container has end gate
which controls part escape.**



**Horizontal or Space Saver Hopper for receiving parts dumped
by operator. Hopper meters parts to feeder with zero drop to
minimize potential for part damage.**

□CDS LIPE * 7650 Edgecomb Drive * Liverpool, N.Y. 13088 * 800-448-7822

Live & Gravity Part Supply Hoppers

FEATURES:

- Interchangeable w/ any type of part feed system
- Provides a buffer for parts to feeder
- Automatically transfers gently to part feeder

BENEFITS:

- Can accommodate a wide variety of parts .25 cu ft to 20 cu ft. Cu Ft Std.
- Can also use a wide range of side or bottom dump containers.
- Can be fully integrate to any style of part feeder
- Maximize feed system efficiency, prevent under populated or overpopulated tooling.
- Brushed Lined part contact surfaces provide gentle handling - reduces part on part recirculation contact

SPECIFICATIONS:

Weight Capacity: (Gravity Hopper)	Up to 500 lbs.*
Weight Capacity: (Live Hopper)	Up to 2000 lbs.*
Weight Capacity: (Live Pan)	Up to 8,000 lbs.*


Overall Dimensions: .25 cu ft to 20 cu ft.

- Larger systems can be designed to accommodate larger capacity hopper using Pan Styles hoppers to either discharge materials from existing container positioned on stand or to receive material dumped in bulk from container.

- Construction: Heavy Gauge Mild Steel
304 SS
316 SS – Seamless, Polished Welds
Lined Hopper

(For Bar, Round, Tube, Rod Magazine Style Hopper please see **Belt Feeder**)

**Live Pedestal Hopper w/ Brushed Pan
Buffer Supply to 929 Part Feeder**



□ CDS LIPE * 7650 Edgecomb Drive * Liverpool, N.Y. 13088

Dyna-Slide®